

STRESS PATTERN FACTORS

These 14 STRESS PATTERN FACTORS give you more insight concerning the history, present effect and future impact of your Organ Trauma Sequence (OTS).

1. STRESS RESISTANCE: This is the amount of resistance you still have in reserve to deal with the issues created because of the organ(s) in your CORE (MemGram®). A low factor indicates a high need for SPRX.

2. PROCESSING VOLTAGE RISK: "Processing" your Traumas causes a dematerialization of your OTS. When you dematerialize an OTS, the reaction you get is whatever your CAUSE is about. It is similar to the "jack in the box" effect. Processing the individual Traumas is like slowly turning the crank. When you have processed all your Traumas, and thereby dematerialized your OTS, the "jack in the box" springs up with great force. The amount of force can have varying degrees of impact on your life. The Processing Voltage Risk Factor indicates the amount of risk involved and how much of an impact MemGram® Processing this OTS is going to have on your life. The higher the factor, the more force the CAUSE will spring at you when you dematerialize this OTS. Thus, you can predict the intensity and type of real life experience that will happen to you. A high factor indicates a high need for SPRX.

3. CONTROL LOSS: This is the amount of control you have lost with regard to your CORE issues. The higher this factor the more you are a victim and the more helpless you see yourself with regard to being able to be in control of the issues surrounding your CORE emotions. A high factor indicates a high need for SPRX.

4. GENETIC LEGACY: Sometimes your problems are not of your own making. They can be ancestral problems that have been passed on to you by blood. This factor indicates whether it is something you have done or whether it is a genetic problem you must overcome. The higher this Factor the more genetic legacy is involved in your Trauma Sequence. A high factor indicates a high need for SPRX.

5. AWARENESS: This is the amount of awareness you can be expected to have concerning the CORE issues that need to be addressed in order to dematerialize your OTS. The higher the factor, the easier it is to process your Traumas. The lower this factor, the more you need the SPRX.

6. CORE ENERGY LOSS: This is the amount of energy loss that has been experienced by your CORE organs. The higher this factor, the more difficult it is to deal with the CORE issues due to lack of vitality and strength of that area. A high factor indicates a high need for SPRX.

7. DEMATERIALIZATION ENERGY GAIN: This is the amount of additional energy you can be expected to feel as a result of processing your Traumas and dematerializing your OTS. The higher this factor, the more energy you can be expected to have as a result of processing your Traumas. A low factor indicates a high need for SPRX.

8. WILL POWER: This factor indicates the amount of willpower you can be expected to have, especially as it has to do with your CORE issues. The higher the factor, the easier it will be for you to track the dragon. A low factor indicates a high need for SPRX.

9. GRAVITATION: This factor indicates the degree of pressure the CORE issues are applying against you. The higher this factor, the more pain, irritation, and pressure you have in your life regarding your CORE issues. A high factor indicates a high need for SPRX.

10. RADIATION: This factor indicates the degree of sensation, loss and space you have in your life regarding the CORE issues. The higher this factor, the more sensitive you are, especially to the core issues. A high factor indicates a high need for SPRX.

11. DETOXIFICATION NEED: This factor indicates the degree of need for detoxification. This may be on a physical or emotional level. The higher this factor is the more detoxification is needed. A high factor indicates a high need for SPRX.

12. PROCESSING EXPECTATION: The greater this factor is, the more you will be emotionally uplifted by processing your Stress Pattern. Sometimes you have to expect little emotional charge from processing your Traumas. Sometimes there is a great deal. This factor helps you know what to expect. A low factor indicates a high need for SPRX.

13. VOLATILITY: This factor lets you know what kind of Stress Pattern intensity with which you have to deal. Think of your Stress Pattern as your "Dragon." As you process your Traumas you are making life difficult for the Dragon. Sometimes you have a sleeping Dragon that you can beat on and he will just roll over and ignore you because he doesn't take you seriously. This is low volatility. Sometimes you have a Dragon with a high degree of volatility. When you beat on him he snaps back and tries to bite your arm or leg off. The higher this factor, the more likely you will have some intense life experiences as you begin to dematerialize your OTS through the processing of your Traumas. A very volatile dragon can make your life very intense as you begin to track him and call attention to his manipulations over you. The higher this factor, the more you may need to use the "reversal" technique for the SPRX to help you through times of crisis.

14. DRAGON GRIP: This is a measurement of the tightness of grip the Dragon has on you. If he is worried about you catching on to his ways he will maintain a tight grip (high % factor). If he doesn't take you seriously he will maintain a loose grip (low % factor). He wants to maintain as loose a grip as possible so he doesn't have to work any harder than necessary. A high % usually means that it may take a little extra effort to get free of the dragon. A low % means it will be relatively easy to get free of the dragon. A high factor indicates a high need for SPRX.

15. SPRX Intensity: This is a measurement of the expected benefit from using the SPRX. A percentage greater than 40% means that physical, mental and emotional benefits can be expected and the SPRX are highly recommended. The SPRX can be used to speed up Stress Pattern detox or to slow it down in times of crisis. DEFINITIONS: DRAGON: A term used to help you visualize your Stress Pattern; your negative energy pattern that surrounds you and creates the resistance through which you live your life; your addictive emotional processes that make you a victim of your past instead of the creator of your future. There is a war between you and your Dragon. Who wins depends upon your commitment to MemGram® Processing.

FOR RESEARCH PURPOSES ONLY – NO DIAGNOSIS INTENDED NOR IMPLIED This report is adapted from "Secret of SAF" by Joseph R. Scogna. <http://www.scogna.com>, 610-678-0200, 610-678-8567-fax
Copyright 2009 BIRI, <http://www.biri.org>, 888-221-4116